

BABY LOCK SERGER ACCESSORIES

Clear Foot

(BLE3ATW-CLF)

Instructions

Use this foot for better visibility when attaching ribbon and lace, or guiding lightweight decorative stitching. The raised guidelines on the foot ensure that you stitch with accuracy. This foot is perfect for decorative construction.



Use the clear foot for better visibility when attaching ribbon, lace, or for guiding lightweight decorative stitching.


MACHINE SETTINGS

Any stitching application can be used (Select one and check the instruction manual for length and width setting for specific stitch selection).

1. Place fabric under the presser foot directly below the needles.
2. Lower the presser foot.
3. Start to serge slowly.
4. The next seam can be started at the toe of the presser foot.
You only need to raise and lower the presser foot when working with thick fabrics or when precise positioning is required.

Note: Be careful not to push or pull the fabric.
The Imagine Wave will feed the fabric evenly without help.

Hint: Insert tape or ribbon into the slot in the front of the foot, then under the sole of the foot. The raised markings on the toe of the foot are needle position guides for decorative techniques.



FOR THE LOVE OF SEWING